























S3K80-90/6E

















S3K80-90/6E

		Code	Description	Qty
1		203346A	Bearing support	1
2		204470B	Magnetic plug	1
3		203370P	Breather plug	1
4		203405P	Oil dipstick	1
5		3VTE002	Screw	8
6		203903A/A	Cover	2
7		203355F	Gasket	2
8		3AT007	Seal ring	2
9		3CU009	Ball bearing	2
10		209274H06	Shaft	1
11		3LI036	Key	1
12		3AP004	Seal ring	1
13		214744T/A	Twiner stuffing-box flange	1
14		213783F	Stuffing-box ring	6
15		3VP006T	Stud bolt	2
16		3DEA010T	Nut	2
17		207155A	Pump body	1
18		3VP021	Stud bolt	4
19		3DEA014Z	Nut	4
20		3NO019	Plug	1

S3K80-90/6E

		Code	Description	Qty
21		3RA004	Washer	1
22		3NO019	Plug	1
23		3RA004	Washer	1
24		3NO019	Plug	8
25		3RA004	Washer	8
26		208972A/A	Diffuser shell	5
27		206519A/A	Diffuser ring	6
28		207158A00	Impeller	6
29		215158I	Wear ring	12
30		3LI010	Key	6
31		205962T	Spacer	5
32		3OR007	O-Ring	6
33		3VP050	Tie rod	8
34		3DEA014Z	Nut	8
35		3RB014Z	Washer	8
36		212554A/A	Suction cover	1
37		206545N	Washer	1
38		218381N	Self-locking nut	1
39		206979C	Bearing	1
40		206288N	Foot	1

S3K80-90/6E

		Code	Description	Qty
41		3VTE016	Screw	2
42		3RB010Z	Washer	2
43		3RA004	Washer	1
44		3RR030	Washer	1
45		3NO009	Plug	1
46		3NO019	Plug	1
47		3RA004	Washer	1
48		3RA005	Washer	1
49		209009Q510	Bush	1
50		209010Q	Bush	1
51		208968C	Bush	5
52		3CU081	Ball bearing	1
53		3RR011	Washer	1