






































T3K80-90/2E-TW - R.6,38

		Code	Description	Qty
1		205153A/A	Gear box	1
2		3VP016	Stud bolt	6
3		3DEA012Z	Nut	6
4		3VTE027Z	Screw	2
5		3RE012Z	Washer	2
6		213820P	Breather plug	1
7		205131G	PTO shaft	1
8		205140G	Gear	1
9		205132N	Spacer	1
10		3CU009	Ball bearing	1
11		3CU134	Ball bearing	1
12		205129A/A	Cover	1
13		3OR004	O-Ring	1
14		205127A/A	Cover	1
15		205148F	Gasket	1
16		3AT010	Seal ring	1
17		3VTE002	Screw	3
18		205154B	Cover	1
19		205147F	Gasket	1
20		3VTE001Z	Screw	8

T3K80-90/2E-TW - R.6,38

		Code	Description	Qty
21		204470B	Magnetic plug	1
22		208912G	Shaft with pinion	1
23		3LI010	Key	2
24		3CU020	Ball bearing	1
25		3CU021	Ball bearing	1
26		205128A/A	Cover	1
27		3AT006	Seal ring	1
28		3OR004	O-Ring	1
29		3AFI008	Seeger	1
30		3AP004	Seal ring	1
31		205149F	Gasket	1
32		206411A/A	Pump support	1
33		205201F	Gasket	1
34		209035A	Pump body	1
35		3NO009	Plug	1
36		3VP006T	Stud bolt	2
37		3DEA010T	Nut	2
38		3VP021	Stud bolt	6
39		3DEA014Z	Nut	6
40		3VP045	Tie rod	8

T3K80-90/2E-TW - R.6,38

		Code	Description	Qty
41		3DEA014Z	Nut	8
42		215158I	Wear ring	1
43		3NO019	Plug	2
44		213783F	Stuffing-box ring	6
45		214744T/A	Twiner stuffing-box flange	1
46		207158A00	Impeller	1
47		205962T	Spacer	1
48		208972A/A	Diffuser shell	1
49		215158I	Wear ring	2
50		207158A00	Impeller	1
51		218381N	Self-locking nut	3
52		206519A/A	Diffuser ring	8
53		3NO019	Plug	2
54		3OR007	O-Ring	1
55		212554A/A	Suction cover	1
56		3NO019	Plug	1
57		215158I	Wear ring	1
58		3OR007	O-Ring	1
59		206979C	Bearing	1
60		206418N	Foot	1

T3K80-90/2E-TW - R.6,38

		Code	Description	Qty
61		3VTE004	Screw	1
62		3RB010Z	Washer	1
63		204477P	Universal joint guard	1
64		3RR030	Washer	1
65		206545N	Washer	1
66		208968C	Bush	1
67		3RB008T	Washer	1
68		205464F	Gasket	1
69		3RB006	Washer	1
70		3RA005	Washer	1
71		3RA004	Washer	8